ASSEMBLY INSTRUCTIONS FOR YOUR

MICHAEL BERMAN LIMITED BOND OUTDOOR PENDANT

IMPORTANT SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety.
- * It is very important that they are read completely before beginning the installation of your fixture.
- * WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.
- * Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- * This fixture is UL rated for wet locations.

ASSEMBLY INSTRUCTIONS:

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/ CIRCUIT BREAKER.
- 2. Remove all parts carefully from the carton. Do not throw away any parts.
- 3. Remove mounting plate (A) from canopy (D) by removing canopy screws (C). Set canopy screws (C) aside.
- 4. Carefully pull the wiring from the ceiling outlet box. Thread the wires through the center hole in mounting plate (A).
- 5. Affix mounting plate (A) to ceiling outlet box with mounting screws (B), provided.
- 6. Measure desired drop for fixture to hang and add/remove chain links (G) with chain break tool (not included).
- 7. Secure quick link (F) to hang straight (E).
- 8. Guide wire exiting the fixture through chain (G), quick link (F), through the center of the hang straight (E), and up through the hole in the canopy (D).
- 9. Cut the cord to the desired length to make electrical connections. Note: At least 8 inches of wire is needed to make proper electrical connections.
- 10. Lift canopy (D) to mounting plate (A) and make proper electrical connections described in steps 11-13. A LICENSED ELECTRICIAN IS RECOMMENDED.
- 11. Attach ground wire from the fixture (green or copper in color) to the ground wire in outlet box. Fasten wires together with wire nut (I) and tightly wrap connection with electical tape.
- 12. Attach hot wire from fixture (black in color, or smooth side of wire) to hot wire from ceiling outlet box. Fasten wires together with wire nut (I) and tightly wrap connection with electrical tape.
- 13. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from ceiling outlet box. Fasten wires together with wire nut (I) and tightly wrap connection with electrical tape.
- 14. Gently push wire conections back into ceiling outlet box. Slide canopy (D) over mounting plate (A). Thread screws (C) into holes in canopy (D) to secure fixture to ceiling.
- 15. Install three 100W MAX. Type A, medium base bulb into socket (H).
- 16. Reconnect main electrical suppy from the fuse box/ circuit breaker and test the fixture.



