

ASSEMBLY AND INSTALLATION INSTRUCTIONS

CF33012

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

Installation Steps

1. Attach two screws to the mounting strap, and then secure with two lock nuts. **(You can adjust the length of the screws if necessary.)**
2. Attach the mounting strap to the ceiling box by using two mounting screws.
3. Make wire connections with wire nuts:
 - Connect the black wire from fixture to the black wire from power source.
 - Connect the white wire from fixture to the white wire from power source.
 - Attach the grounding wire and house grounding wire to the mounting strap with a green grounding screw.Carefully tuck wires back into the ceiling box. □
4. Attach the canopy to the mounting strap, and secure with the bolt nuts.
5. Install bulbs. **(Please do not exceed the maximum capacity, which is recommended on the package.)**
6. Attach the rubber pad upward to the box. Then Place the glass shade and antler through the nipple. Then secure them with the finial.
7. Turn on the power at fuse or circuit box.

